


User Guide Bar-code Scanner Solution

Spectacle Hut



Flow Chart





Content Page

When Bar-code Scanner is not working

1. Scanning ray of bar-code scanner	Page 4
1.1 Open excel and scan bar-code	Page 5
1.12 Scan bar-code into sales or inventor	y sheetPage 6
1.13 Call Frontwave to check POS	Page 6
1.2 Scan bar-code of different product	Page 6
1.21 Contact headquarters for reprint of b	ar-codePage 6
1.22 Call It personnel for printer reset cod	ePage 6
2. Unplug bar-code scanner wire	Page 6
2.1 Check for beep or red scanning ray .	Page 6
2.2 Trace and tighten cable	Page ·



Solution for problems of Bar-code Scanner


This section would teach you how to solve the problems that you encounter on the bar-code scanner.

When Bar-code Scanner is not working:

1. Press button on the <u>scanner</u>, check if there is a red scanning ray.



Red scanning ray on the bar-code scanner







1.1. If there is a red scanning ray on the <u>bar-code scanner</u>, open <u>excel</u> and scan a bar-code of a product into the excel sheet



Click "All programs", "Microsoft Office" and finally "Microsoft Office Excel 2012"




Bar-codes in Excel sheet





- 1.12 If there is bar-codes scanned into the excel sheet, try scanning it again in sales or inventory.
- 1.13 If the bar-codes did not appear on the Sales or Inventory, please call Frontwave to check POS.



- 1.2 If the bar-codes did not appear on the excel sheet, try to scan the bar-code of a different product.
- 1.21 If the bar-codes appear on the excel sheet, please contact HQ to request for a reprint of the bar-code.
- 1.22 If the bar-codes are still not appearing on the excel sheet, please call IT personnel to send the printer reset code.
- 2. If there are no red scanning ray on the bar-code scanner, please plug off the bar-code scanner and put it back to check for any red light or beep.

Unplug the Bar-code Scanner wire



2.1 If there is a beep or the red scanning ray, please try to scan again.



2.2 If there is no beep or red scanning ray, please trace the cables and tighten it. Restart the computer if it still does not work.