





User Guide

Monitor Solution

Spectacle Hut

Flow Chart



Content Page

When Monitor is not working

1. Check if monitor is switched on	Page 4
1.1 Switch on monitor again	Page 4
2. Check the signal on monitor	Page 4
2.1 Check the power socket	Page 4
3. Signal on monitor is displaying orange light	Page 5
3.1 Data cable connection for both monitor and CPU	Page 5
4. Signal on monitor is displaying green light	Page 6
4.1 Adjust brightness buttons	Page 6
4.12 Call IT personnel for monitor replacement	Page 7

Solution for problems of Monitor

This section would teach you how to solve the problems that you encounter on your monitor.

When Monitor is not working:

1. Check to see if the monitor is switched on.
 - 1.1 If it is not on, switch it on again.
2. If the monitor has been already switched on or still not on yet, check to see if there is any signal on it.
 - 2.1 If there is no signal on the monitor, check your power socket.

Check your power socket



3. If there is signal on the monitor, check to see if its showing orange light instead of green light

Signal of monitor displaying orange light




3.1 If the signal of the monitor is showing orange light, it means that the data cable is loosed. Check the connection of the data cable for both the monitor and the CPU.

Check the data cable connection on the CPU




Check the data cable connection on the monitor




4. If there is signal on the monitor, check to see if it is displaying green light instead of orange light.

Signal of monitor displaying green light



4.1 If the signal of the monitor is displaying green light, try to adjust brightness control buttons.

Adjust the brightness on the monitor



4.12 If adjusting the brightness buttons does not solve the problem, call the IT personnel for monitor replacement.