




User Guide

Television Solution

Spectacle Hut

Flow Chart



Content Page

When Television is not working

1. Signal light on the television	Page 4
1.1 Check power cable or sockets	Page 4
2. Check the color of the signal light	Page 5
2.1 Television in idle mode	Page 5
3. Text displayed on television	Page 6
3.1 Player has stopped playing	Page 6
3.2 Adjust the brightness or contract button and call for IT support	Page 7

Solution for problems of Television

This section would teach you how to solve the problems that you encounter while operating the television.

When television is not working:

1. Check the signal light on the television.

Signal light on the Television



- 1.1 If there is no signal light on the television, check the power cable or sockets.

Check power cable or sockets



2. If there is signal light on the television, check if the signal light is red in colour.

Signal light on television is red in colour



2.1 If the signal light is red in color, it means that the television is in idle mode. Activate it by remote control or pressing the power button at the side of the television.

Television on idle mode



3. If the color of the signal light is green instead of red, check if there is any text on the television.

Signal light on television is green in color



3.1 If there is text or a logo moving around on the television, it means that the player has stopped playing. You could check the setting on the player to set it to auto play or auto looping. However, if the message says no input signal, please check the player.

Moving Logo on the television screen



3.2 If there no text on television, try to adjust the brightness or contract buttons. Please call for IT support if it still does not work.

Press the “menu” button on the television



Adjust the brightness as show on the television screen

